

Cleaning & Maintenance Guide

How to care for and maintain your Luxtone Floor





Daily Schedule

For day-to-day cleaning, its essential to dust your vinyl flooring with a microfibre mop or cloth each day to prevent any scratches and surface damage. Microfibre cleaning pads use static electricity to trap dirt, particles and other household allergens.

Dusting the surface will remove any particles of dust and grit that may appear from footwear, chair legs and will contribute to preventing the floor from long-term damage.

Household brushes may also be used, but please be aware that these can simply push the dirt around and may potentially cause scratches to the floors surface.

The use of Steam Mops and Wet Mops

The use of steam mops and wet mops as cleaning methods can damage the surface and underlying structure of Luxtone flooring, leading to issues such as warping, discolouration, and weakening of the material. These damages are not covered under the warranty, to prolong the lifespan of your flooring we strongly advise against the use of excessive moisture and heat.

Weekly Schedule

On a weekly basis, we recommend giving your vinyl flooring a vacuum or slightly moist mop to get rid of more stubborn stains or debris that may have dried onto the surface.

When using a vacuum, pay close attention that there are no protruding parts around the tools that may cause damage to the surface of the floor.

When using a mop, any excess water should be removed from the floor. Never pour water directly onto the floor's surface as this can cause swelling, warping, de-lamination and even joint separation and not only reduce your floors lifespan, it will also most likely void any manufacturers' warranty.

To maintain the warranty and ensure the longevity of your Luxtone flooring, it is essential to follow the recommended cleaning methods as outlined above. By adhering to these guidelines, you can protect your new floor and enjoy the durability and aesthetic appeal of your Luxtone flooring for years to come.